




theBoom "O" Quick Start Guide



Bend the Boom to ensure that the microphone is about 1 inch from the corner of your mouth, and facing your lips.



Plug the adapter cable into the universal connector. The supplied adapter works with most cell phones and cordless phones.



The earphone volume is controlled by the small black thumbwheel. To mute the microphone, press and hold the mute button.